

Antisilikon AS

Recommendations for processing

AS Anti-Silicon can be used in all coloured and clear lacquers containing solvents if the surface has been scratched by silicon craters.

As a rule, you add 10ml for every 1 litre of lacquer. AS anti-silicon must be stirred well into the lacquer.

All subsequent lacquer layers must also contain AS Anti-silicon, to avoid any surface flaws.

Zweihorn products are produced for the professional user, who has a basic knowledge of the stockturn and the application of stains, varnishes, glazes and glues. The user information for our qualities given in the leaflets should be regarded as non-binding recommendations. They are based on our test series and experiences and should facilitate and promote the work of our clients. A possible necessary adjustment to the individual working conditions lies within your responsibility. If in any doubt, our material experts as well as our application and laboratory technicians will try to help you as best as they can. We guarantee of course the impeccable quality of our products based on our General Sales and Delivery Conditions. All current technical data sheets are herewith voided. The use of the final product lies entirely within the responsibility of the buyer. As long as we haven't guaranteed in writing specific characteristics and suitabilities of the products for a contractually agreed purpose, any advice or information given regarding the application, even if the advice or information is given to the best of our knowledge, will be non-binding. Nor does it relieve the buyer, either from his own inspection, and if need be through a trial processing. Furthermore, we are only liable according to Chapter 1 of our General Conditions for advice either given or rejected, which does not refer to the characteristics and use of the delivered product.